

ML710_REC_MK3 Paper Towel Dispenser & Waste Receptacle Recessed

Note

This product is to be installed by suitably qualified persons, in a fit-for-purpose application, to suitable materials, using suitable fixings, and complying with any relevant codes.

Dimensions


- **Overall Size:** 710mmH x 350mmW x 95mmD
- **Wall Opening:** 685mmH x 325mmW x 95mmD

Hardware Provided

- 4x Screws
- 4x Wall Plugs
- 4x Keys (Spare keys can be ordered using the part number ML706-710_MK3_KEY)

Before Installation

- Inspect the product. If there is any damage or missing parts, do not install the product and contact your place of purchase.
- Ensure the surface you wish to mount the unit to is either solid or has adequate in-wall support.
- Ensure the surface you wish to mount the unit to is flat.
- Check that there will be adequate clearance for the paper towel dispenser to be opened once installed. (The door is hinged on the right-hand side.)
- Two people are required for installation.



This product is accessible compliant when installed in accordance with AS 1428.1 guidelines.

The photographs and line drawings of the products presented above are representational only. Metlam Australia Pty Ltd reserves the right to, and from time to time, make changes and improvements in design and dimensions.

Installation Instructions

Placement may be subject to regulations/codes and architectural drawings. Correct positioning is the responsibility of the installer.

1. Create a wall opening 685mmHigh x 325mmWide x 95mmDeep.
2. Unlock the paper towel dispenser and waste receptacle with the keys provided. Remove the waste receptacle and open the paper towel dispenser door to locate the mounting holes.
3. Lift the unit into the wall opening, and checking that all sides are level, mark the four mounting points on the studs through the holes.
4. Install four suitable fasteners into the studs at the marked locations and mount the unit.
5. Apply neutral cure silicone to all edges where the unit meets the wall.
6. Reinsert the waste receptacle into the unit, close the paper towel dispenser door, and lock both.
7. Test unit for correct operation.
8. Retain the keys for the end user.

Note Regarding Accessible Compliance:

"Where provided, ... towel dispensers ... shall be operable by one hand, and shall be installed with the height of their operative component or outlet not less than 900 mm and not more than 1100 mm above the plane of the finished floor, and no closer than 500 mm from an internal corner."

- AS 1428.1:2021 clause 12.4.3

Technical recommendations and installation advice from Metlam Australia Pty Ltd are general in nature and provided in good faith without warranty. Metlam disclaims all liability for errors, omissions, or damage resulting from improper installation or maintenance. All products must be installed by qualified tradespeople and maintained by competent personnel. It is the installer's responsibility to conduct thorough pre-installation assessments; Metlam Australia will not enter into post-installation disputes regarding positioning, functionality, or external factors affecting performance.