




MATERIAL SPECIFICATION & INSTALLATION GUIDE

PRODUCT ITEM CODE & DESCRIPTION:

ML 635 ~ ABS - 475ml LIQUID SOAP DISPENSER



MATERIAL SPECIFICATIONS / FEATURES:

ABS body with integrated mounting bracket – Buff~Grey Finish / Pump Type Valve / Lockable Filler Cap (key provided) / Soap Level Indicator / Fixings included

DIMENSIONS:

Overall ~ 97mm W x 185mm H x 119mm (incls 30mm pump protrusion)D

INSTALLATION GUIDE:

1. May be subject to Australian Building Code Regulations for height/location fixing and/or subject to placement as per architectural drawings, which in all cases is the responsibility of the installer re compliance.
2. Unit is provided with integrated mounting bracket & fixings
3. Locate mounting holes, position at required height on wall and mark using fixing holes, ensuring unit is level and even. Measure/Check Twice ... Drill Once
4. Drill holes, position unit and loosely secure to wall surface using appropriate screws/wall-plugs
5. Check level and tighten fasteners, lock lid to ensure operational.

NOTE: Quality, liquid soap (not included) *must* be of an adequate viscosity to ensure correct soap valve function and operational integrity/longevity of the unit.

These units should only be installed by a competent tradesperson and Metlam Australia takes no responsibility for any damage to walls or fixtures due to incorrect installation.