

CORRECT CHOICE OF CONSUMABLES FOR METLAM AUSTRALIA DISPENSERS (SOAP, TOILET ROLL & PAPER TOWEL)

METLAM AUSTRALIA DISPENSER GUIDELINES

As Metlam Australia does not sell consumable products, the products listed below reflect the most popular range of consumables in the market. There are also many product equivalents that can be successfully utilised in Metlam Australia dispensers, use below as a guide to the Metlam Australia suitability requirements. Please note, Metlam Australia recommends that any consumable is trailed prior to being purchased to ensure suitability as manufacturers of products may change dimensions and ingredients without notification to Metlam Australia.

GUIDING PRINCIPLE

The key to finding the correct products to put in your Metlam Australia dispenser is knowing the width and depth of your product and maximizing the internal space available.

Note: If the paper is too narrow it may fall out of the dispenser in clumps and if the soap is too thick and thin, it may block the pump and leak through the valve.

WHAT TYPE OF SOAP DO I USE IN MY METLAM AUSTRALIA SOAP DISPENSER?

- Metlam Australia recommends the use of commercially available liquid soap. The soap used in our Stainless Steel Dispensers should preferably:
- Be coconut and vegetable oil based;
- Have a neutral pH (6.5 - 9.0) and;
- Be free from any alcohol, solvents and abrasive particles. The use of these can cause irreparable damage to your dispenser including staining, corrosion, degradation of the plastic and rubber inside the valve and can void your warranty.

For liquid soap it should be viscous and have a thickness between 1,000 and 5,000 CPS (centipoises). For foam soaps, a thinner viscosity soap, <1,500 CPS, is recommended for adequate flow.

Liquid and foam soap viscosity will change dependent on the ambient temperature. A good rule of thumb to follow is that the soap should flow freely at room temperature. Remember, thinner soaps are more likely to leak from your valve and thicker soaps lower the dosing volume and can potentially clog the dispenser.

CONSUMABLE SUPPLIERS

Consumable products recommended for Metlam Australia Dispensers on this document can be purchased from these suppliers:

- [Caprice Paper](#)
- [John S Hayes](#)
- [Melbourne Cleaning Supplies](#)
- [Officeworks](#)
- [Office Choice](#)

For further Consumable advice contact your local Metlam Australia Business Development Manager, Regional Sales Manager and contact our Head Office on 1300 METLAM.

Metlam Dispenser Code	Dispenser Type	Overall Dimensions (Storage Compartment)	Suitable Products Available
Liquid Soap			
ML606 and ML615B	Commercial Grade Liquid Soap Viscosity Range: 1,000 - 5,000cps (centipoises) pH Range: 6.5-9.0	400mL	Hexa 070101 and 070104 Northfork 635010700, 635010800 and 635020700 Regal RSOAP5L and RSOAP5WL
ML616_4 and ML616_6		475mL	
ML635		475mL	
ML655 and ML663		600mL	
ML610		700mL	
ML_950SD_SS		900mL	
ML628_4 and ML628_6		950mL	
ML_950DA_WHT		950mL	
ML600, ML602, ML603, ML605, ML640AS, ML641AS and DESIGNER_ML605BAS		1.2L	
Foam Soap			
ML681F	Foam Hand Soap	750mL	Supreme Clean 072301 and 072201
ML681SSF	Viscosity Range: <1,500 cps (centipoises)	1000mL	
ML_MSD_FOAMDISP_SS		800mL	
Paper Towel			
ML_ECO_73N1REC and ML_ECO_73N1SM	Interfold or Interleaved Paper Towel	257mmW x 106mmD	Enviro~Saver ES150 Tork 0170370, 2310769 and 148430 Kleenex 4456 Scott 13207 and 4457 Caprice 4000CU and 1620CW
ML_ECLIPSE_3N1REC_D		265mm W x 80mmD	
ML707			
ML710			
ML725		282mmW x 104mmD	
ML726			
ML705, ML706 and ML727	Slimline Folded Towel	265mmW x 70mmD	Scott 60218 and KI5855 Enviro~Saver ES162 Tork 0148430 and 0184987 Kleenex KI44400KT and KI44400
ML4093SS, ML4093W, ML4093SS_LOCKABLE and ML4093W_LOCKABLE	Paper Towel Roll	220mmW x 180mmD	TruSoft TRT100 and TRT80 Tork 2187951, SC56081 and SC290016

Toilet Roll & Paper			
ML113, ML513, ML225, ML256, ML260, ML261, ML262, ML263, ML267, ML800, ML801, ML820, ML820A, ML825, ML832, ML833, ML835, ML836, ML837, ML838, ML3355B, ML949_375, ML5856, ML6000, ML6002, ML6004, ML6048, ML6049, ML6050, ML6224, ML6225, ML6226, ML4135, ML4135_2, 700_SS_TRH, 700_SS_2TRH, MLR50TPH and MLR50NCAL_TPH	Standard Toilet Roll	Up to 400 Sheets per roll	Scott KI57410 Tork SC23400, SC2170329 and 0127530 Kleenex KI4737 ad KI4735 Regal B2400V
ML4094SS & ML4094W	Interfold Toilet Paper	142mmW x 242mmH x 43mmD	Kimberley Clark KI4301 Regal IT4001 and IT2502
ML840, ML841, ML841DBL, ML842, ML843 and ML862	Jumbo Toilet Roll	Jumbo Rolls up to 300mL	Enviro~Saver ESJ300 TruSoft JR3002R Stella ST3000
Facial Tissues			
ML275_BSM	Facial Tissue	267mmW x 64mmD	Regal FT1002 Tork 2311408 Kleenex KI04720
Air Freshener			
ML230AD	Auto Air Freshener	Replaceable Commercial Aerosol	Air Wick 8141111, 8141113 and 8141115

The technical recommendations contained in this document are necessarily of a general nature and should not be relied upon for specific applications without first securing competent advice. Whilst Metlam Australia Pty Ltd has taken all reasonable steps to ensure the information contained herein is accurate and current, and in accordance with ASSDA recommendations, it does not warrant the accuracy or completeness of the information and does not accept liability for errors or omissions. Any Commercial product should only be installed by a competent tradesperson and serviced/maintained by knowledgeable janitorial staff or competent people. Metlam Australia accepts no responsibility for any damage to product, walls or fixtures due to incorrect installation or maintenance of any of their products.